



Tuscany Accent

Product Data Sheet

Description:

Tuscany Accent is a stain used in combination with UltraKote finishes to achieve an "Old World" or "Antique" appearance.

Uses:

Tuscany Accent is for interior or exterior applications when the "Old World" or "Antique" look is desired.

Color:

All standard UltraKote Colors with Custom Colors on request.

Packaging:

32 fluid ounce Plastic Jar.

Coverage :

Coverage varies greatly due to the desired look and the application technique used.

Mixing:

Stir the jar vigorously before use.

Surface Preparation:

Surface for the Tuscany Accent Stain should be a "just applied" or "wet" layer of UltraKote Finish.

Application:

Apply one coat of UltraKote Finish as directed (see specific Finish Product Data Sheets) with a stainless steel trowel or approved spray equipment. Allow to dry cure out completely. Apply a second layer of UltraKote Finish. While the second coat still wet randomly spray Tuscany Accent within your working area using a spray bottle. Work the stain into the finish with a stainless steel pool finishing trowel. Randomly add more Tuscany Accent Stain until the desired look is achieved.

Curing/Drying:

Drying time averages 4 hours depending on the ambient temperature, surface, surface temperatures and humidity. Finish fully cures within two weeks.

Storage/Shelf Life:

Product is good for one year when stored in a cool dry place and out of direct sunlight. Keep from freezing.

Clean Up:

Clean tools and equipment with water immediately after use.

UltraKote Products, Inc.

327 S. 27th Avenue
Phoenix, AZ 85009
Phone: (602) 272-5830 • (800) 224-2344

Last Revised : March 2006

Tuscany Accent

Product Data Sheet

Precautions:

KEEP OUT OF THE REACH OF CHILDREN. Not for internal consumption. Do not apply in non-ventilated area. Use protective equipment such as gloves, eye protection and clothing.

First Aid:

In case of eye contact, flush with water at least 15 minutes. In case of skin contact, wash affected areas with soap and water. If irritation persists, SEEK MEDICAL ATTENTION. Remove and wash contaminated clothing. If inhalation causes physical discomfort, remove to fresh air. If discomfort continues or any breathing difficulty occurs or if swallowed, SEEK IMMEDIATE MEDICAL ATTENTION. For additional information refer to the Tuscany Accent Material Safety Data Sheet (MSDS).

Disposal:

Dispose of in accordance with local, state or federal regulations.

Warning:

KEEP OUT OF REACH OF CHILDREN. NOT FOR INTERNAL CONSUMPTION, FOR INDUSTRIAL USE

Spills:

Scrape up and wash with water immediately. If material has set, scrape material with appropriate tools and clean with citric acid.

Prop 65:

This product contains materials listed by the state of California as known to cause cancer, birth defects, or other reproductive harm.

Technical Support:

For technical support call 1-602-272-5830. Information contained in this Product Data Sheet conforms to the standard detail recommendations and specifications for the installations of UltraKote products as of the date published on this document. UltraKote Products, Inc. assumes no liability, expressed or implied, as to the architecture, engineering or workmanship of any project. To insure that you are using the latest, most current information, contact UltraKote Products, Inc
