



Typical Insulation Board Layout

PB 1.1




Typical Aesthetic Groove

PB 1.2




Typical Concrete Floor Span

PB 2.1




Typical Frame to Foundation

PB 2.2




Alternate Frame to Foundation

PB 2.3




Typical Inside Corner Termination

PB 2.4




Typical Soffit Drip Groove

PB 2.5




Typical Direct Applied Soffit Return

PB 2.6




Typical Floor Line Expansion Joint

PB 3.1




Typical Flat Room Termination

PB 4.1




Typical EPS Foam Parapet Cap

PB 4.2




Typical Metal Parapet Cap

PB 4.3




Typical Window Sill

PB 5.1




Alternate Window Sill

PB 5.2




Typical Window Jamb

PB 5.3




Typical Window Head

PB 5.4




Typical Window Sill with Decorative Band

PB 5.5




Typical Window Jamb with Decorative Band

PB 5.6




Typical Window Head with Decorative Band

PB 5.7




Typical Inset Window Sill

PB 5.8




Typical Inset Window Jamb & Head

PB 5.9




Typical System Penetration

PB 6.1



Typical Non-Structural Penetration

PB 6.2




Note: This is a non-structural fastening system.

*Set support strap in bed of sealant.

**Sleeve must be 1/4" larger than hole for toggle.

Typical Downspout Attachment

PB 6.3



Typical Exterior Light Penetration

PB 6.4

